

Warm Booting Motorola MC55 Pharmascan Unit

Follow these steps to warm boot the Motorola MC55 unit:

1. Hold the power button down for 5 seconds (Figure 1).
2. The unit will be rebooted.
3. After the boot process is complete, the unit will be ready to use again as per normal.



Figure 1